



## MASSEY VISES.

### Perfect Quick Adjusting.




Fig. D. 461.

The hand grasping the handle-socket and fingers pressing trigger releases the nut from the screw, adjusts the loose jaw against the work and fastens it without the hand leaving the handle.

Stationary Bottom.					Swivel Bottom.				
	Width of Jaw. Ins.	Opens. Ins.	W'ght. Lbs.	Price.		Width of Jaw. Ins.	Opens. Ins.	W'ght. Lbs.	Price.
No. 0	3½	4½	32	\$ 7 75	No. 0	3½	4	40	\$ 8 75
" 1	4½	5½	42	9 50	" 1	4	5½	50	10 50
" 2	5	6	70	11 50	" 2	5	6	78	12 50
" 3	5½	8	109	17 50	" 3	5½	8	118	19 50
" 4	6½	9	140	23 00	" 4	6½	9	150	25 00

Discount.....

### Lightning Grip Vise.




Fig. D. 462

All engaging parts steel. The loose jaw can be instantly adjusted and the work firmly fastened with a quarter turn of the handle. The handle is always out of the way of the workman, as shown in cut, when Vise is in use.

### Stationary or Swivel Base.

No.	Width of Jaw.	Opens.	Price
11	3½ in.	5 in.	\$ 8 50
12	4½ "	6 "	11 50
14	5½ "	8 "	17 50
16	7 "	11 "	30 00

Discount.....